



THE SCIENCE OF SURVIVAL

Part Number	Description
7300	ARTEX 151-6627 TERMINAL 10 PK
7301	ARTEX 151-6628 TERMINAL 10 PK
7302	ARTEX 151-6657 CONTACT 10 PK
7303	ARTEX 151-9702 CONTACT 10 PK
7304	ARTEX 201-0402 SCREW 10 PK
7305	ARTEX 201-0810 SCREW 10 PK
7306	ARTEX 209-0412 SCREW 10 PK
7307	ARTEX 213-0632 SCREW 10 PK
7308	ARTEX 217-0606 SCREW 10 PK
7309	ARTEX 241-0400 HEX NUT 10 PK
7310	ARTEX 241-0632 HEX NUT 10 PK
7311	ARTEX 246-0008 WASHER 10 PK
7312	ARTEX 247-0400 WASHER 10 PK
7313	ARTEX 247-0800 WASHER 10 PK
7314	ARTEX 280-0001 WASHER 10 PK
8100	ARTEX ELT 345 BEACON AND BATT
8102	ARTEX ELT 345 BASE/WHIP/RM SW
8104	ARTEX CABLE CURR DRAW ELT345
8105	ARTEX ELT 345 BUILDERS KIT
8110	ARTEX PLB W/POUCH
8201	ARTEX ELT 1000 BEACON & BATT
8201D	ARTEX ELT 1000 BEACON DEMO
8202	ARTEX ELT 1000 BASE PAC
8203	ARTEX ELT 1000 BASE/WHIP/RM SW
8204	ARTEX ELT 1000 BASE/ROD/RMT SW
8205	ARTEX ELT 1000 ACE/WHP 1.25 CB
8206	ARTEX ELT 1000 ACE/WHP 6' CBL
8207	ARTEX ELT 1000 BASE/ROD/RM SW
8208	ARTEX ELT 1000 LSA KIT
8221	ARTEX ELT 3000 BEACON/BATT
8221D	ARTEX ELT 3000 DEMO
8222	ARTEX ELT 3000 BASE PACK
8223	ARTEX ELT 3000 BASE/ROD 1IN
8224	ARTEX ELT 3000 BASE/BLD 1IN
8231	ARTEX ELT 3000 HM BEACON/BATT
8232	ARTEX ELT 3000 HM BASE PACK
8233	ARTEX ELT 3000 HM BASE/ROD 1IN
8260	ARTEX ELT 4000 BEACON/BATT
8261	ARTEX ELT 4000 BASE PACK
8262	ARTEX ELT 4000 BASE ROD 1IN
8263	ARTEX ELT 4000 BASE BLD 1IN
8264	ARTEX MOUNT STRAP ELT 4000
8271	ARTEX ELT 4000 HM BEACON/BATT

Part Number	Description
8272	ARTEX ELT 4000 HM BASE PACK
8273	ARTEX ELT 4000 HM BASE ROD 1IN
8302	ARTEX ELT 1000 BATT REPL'MT
8303	ARTEX MOUNT TRAY/STRAP REPL'MT ELT 1000
8304	ARTEX ELT 1000 REMOTE SWITCH 2-
8306	ARTEX AKING 451 CONV ELT 1000
8315	ARTEX ELT 3000 REPL'MT BAT/G-SW
8316	ARTEX ELT 3000 MNT BRCKT, METAL
8318	ARTEX ELT 3000 RETRO TRAY & BRKT
8319	ARTEX PA ELT 3000 PROGRAMMED
8320	ARTEX PA ELT 3000 BLANK
8322	ARTEX ELT 345 REPL'MT BATT
8323	ARTEX ELT 345 REPL'M TRAY & STRAP
8324	ARTEX ELT 345 REPL'MT ANT
8340	ARTEX BATTERY ELT 4000
8342	ARTEX MOUNT TRAY ELT 4000
8343	ARTEX COVER ASSY TOP ELT 4000
8344	ARTEX MOUNT CAP ASSY ELT 4000
8506	ARTEX CABLE, PROG ELT 3000/S
8603	ARTEX ANT ROD SGL INPT 3BAND
8700	ARTEX ELT PROGRAMMER HANDHELD
8701	ARTEX TEST SET ELT STD
8709	ARTEX TEST SET BATT RPLCMNT
8715	ARTEX PROGRAMMER GA,ME,345,1000
110-320	ARTEX ANTENNA ROD TRI
110-323	ARTEX ANTENNA ROD DUAL ELEM
110-324	ARTEX ANTENNA WHIP W/INDU
110-328-01	ARTEX ANTENNA BLD
110-329	ARTEX ANTENNA WHIP
110-333	ARTEX ANTENNA BLD 16-22 1IN
110-333-04	ARTEX ANTENNA BLD TRI BLK
110-337	ARTEX ANTENNA BLD TRI 2IN
110-337-01	ARTEX ANTENNA BLD PROTEC EDGE
110-337-11	ARTEX ANTENNA BLD
110-338	ARTEX ANTENNA ROD CI317-1 1IN
110-338-01	ARTEX ANTENNA ROD CI317-1-4 1I
110-340	ARTEX ANTENNA BLD CI319-1 1IN
110-340-01	ARTEX ANTENNA BLD, CI319-1-5
110-341	ARTEX ANTENNA BLD 16-21 1IN
110-343	ARTEX ANTENNA WHIP 21-41
110-343-01	ARTEX ANTENNA WHIP TRI BLK
110-418	ARTEX ANTENNA 1/4 WAVE
110-773	ARTEX ANTENNA WHIP DUAL 1IN
110-775	ARTEX ANTENNA TAPE PORT 1IN
130-4004	ARTEX BUZZER AUDIBLE ALERT
131-0001	ARTEX BATTERY LI 2CR1/3N 6V
140-1733	BOOT, RUBBER SWITCH COVER
150-1120	PLUG, TPS COAX CABLE
150-5061	CONNECTOR, 22 POS. PLUG, SHELL
151-2012	ARTEX PLUG ELT TEST ASSEMBLY
151-2100	CONTACT, SOCKET #20
151-2101	CONTACT, PIN #20

Part Number	Description
151-5009	RECEPTACLE, 9 PIN
151-5060	C406-N TEST LOOP BACK PLUG
151-5061	STRAIN RELIEF, SHELL SIZE 12
280-0340	ARTEX GASKET 110-337 ANTENNA
345-6196	ARTEX SWITCH REMOTE COCKPIT
345-6196-04	ARTEX SWITCH REMOTE COCKPIT
452-0010	ARTEX SWITCH REMOTE (CESSNA)
452-0036	MTL FLOAT COLLAR SLB-406 (DISCONTINUED)
452-0102	ARTEX BATTERY TESTER 452-1001 (DISCONTINUED)
452-0128	ARTEX BATTERY LI 6V
452-0129	MTL BATTERY ASSY SLB-406
452-0130	ARTEX BATTERY ELT 110-4
452-0130-02	ARTEX BATTERY ELT 110-6/100HM
452-0130-03	ARTEX BATTERY BOEING AL
452-0131	ARTEX BATTERY 406 SERIES LI
452-0133	ARTEX BATTERY 406 SERIES LI LM
452-0222	ARTEX BATTERY G406 SERIES LI
452-0227	ARTEX MOUNT TRAY ASSY, YELLOW
452-3034	DISCONTINUED (SEE 452-3034-1)
452-3034-1	ARTEX MOUNT ME 406 METAL YEL
452-3052	ARTEX COVER ASSY, TOP MTG (406)
452-3061	ARTEX BATTERY SURVIVAL SERIES
452-3063	ARTEX BATTERY ELT-200 AL
452-3075	DISCONTINUED (SEE 452-3075-1)
452-3075-1	ARTEX MOUNT ME406P METAL YEL
452-5050	ARTEX MOUNT TRAY ASSEMBLY
452-5052	ARTEX MOUNT CAP ASSY FRAME 406
452-5066	ARTEX MOUNT CAP ASSY C406-N
452-6505	ARTEX BUZZER PIEZO
453-0020	ARTEX SWITCH RMT 28V
453-0020-02	ARTEX SWITCH RMT ASSY 5V
453-0022	ARTEX SWITCH RMT CESSNA
453-0030	ARTEX SWITCH RMT TOGGLE
453-0161	ARTEX PANEL CNTRL BOEING 737
453-1101	ARTEX MODULE INTFC ELT-RMT
453-4010	ARTEX DONGLE DGL-1 MAIN ASSY
453-5000	ARTEX ELT C406-2 M-ASSY
453-5001	ARTEX ELT C406-2HM M-ASSY
453-5002	ARTEX ELT C406-1 M-ASSY 1OUT
453-5003	ARTEX ELT C406-1HM M-ASSY 1OUT
453-5004	ARTEX ELT B406-4 M-ASSY
453-5012	ARTEX ELT G406-4 M-ASSY
453-5056	ARTEX ELT RB406-1HM, M-ASSY (ITAR)
453-5060	ARTEX ELT C406-N M-ASSY
453-5061	ARTEX ELT C406-NHM M-ASSY
453-5068	ARTEX PA C406-N BLANK
453-5078	ARTEX PA C406-N PROGRAMMED
453-6500	ARTEX INTERFACE NAV M-ASSY
453-6501	ARTEX INTERFACE NAV-B M-ASSY
453-6603	ARTEX ELT ME406 M-ASSY YEL
453-6604	ARTEX ELT ME406HM M-ASSY YEL
453-6611	ARTEX ELT ME406P M-ASSY YEL
453-6650	ARTEX ELT ME406 M-ASSY BLK (ITAR)

Part Number	Description
453-9700	ARTEX SWITCH RMT B1-28V BLK
453-9701	ARTEX SWITCH RMT G1-28V GRY
453-9703	ARTEX SWITCH RMT NVP ITAR
455-0011	MTL BEACON SLB 406 PAC (DISCONTINUED)
455-0012	ARTEX BATTERY ME406 KIT YEL
455-0017	ARTEX BATTERY ME406 KIT BLK (ITAR)
455-0023	ARTEX SWITCH SELF-PWR RMT PAC
455-0027	ARTEX SWITCH RMT BELL NVIS
455-0030	ARTEX INSTALL KIT (RMT) LRJT
455-0049	ARTEX INTERFACE ELT/RSWT 2WIRE
455-0775	ARTEX TETHER ASSY BLACK
455-4010	ARTEX DONGLE DGL-1 PAC
455-5000	ARTEX ELT C406-2 BASE PAC
455-5001	ARTEX ELT C406-2HM BASE PAC
455-5002	ARTEX ELT C406-1 BASE PAC
455-5010	ARTEX ELT C406-2 ROD TRI 2IN
455-5011	ARTEX ELT C406-2 BLD TRI 2IN
455-5012	ARTEX ELT C406-2HM ROD TRI 6'
455-5014	ARTEX ELT C406-1 ROD TRI
455-5015	ARTEX ELT C406-1 BLD TRI 1IN
455-5016	ARTEX ELT C406-1HM ROD TRI 1IN
455-5019	ARTEX ELT G406-4 ROD TRI 2IN
455-5029	ARTEX ELT C406-2 ROD TRI RMT
455-5030	ARTEX ELT C406-2 BLADE TRI 2IN
455-5044	ARTEX ELT G406-4 WHIP W/IND
455-5049	ARTEX ELT C406-2HM ROD TRI 10'
455-5060	ARTEX ELT C406-N BASE PAC
455-5061	ARTEX ELT C406-N HM BASE PAC
455-5062	ARTEX ELT C406-N BLD TRI 1IN6'
455-5063	ARTEX ELT C406-N ROD TRI 1IN
455-5064	ARTEX ELT C406-NHM ROD TRI 1IN
455-5071	ARTEX ELT C406-NHM ROD TRI 1IN
455-6196	ARTEX SWITCH NAV REMOTE PAC
455-6500	ARTEX INTERFACE NAV W/INSTLKIT
455-6603	ARTEX ELT ME406 BASE PAC YEL
455-6604	ARTEX ELT ME406HM BASE PAC YEL
455-6605	ARTEX ELT ME406 YEL WHIP
455-6606	ARTEX ELT ME406HM YEL ROD TRI
455-6607	ARTEX ELT ME406 YEL ROD TRI
455-6608	ARTEX ELT ME406 YEL ROD INT
455-6613	ARTEX ELT ME406P YEL ROD TRI
455-6614	ARTEX ELT ME406 YEL WHIP ANT
455-6615	ARTEX PACK LIST ME406P BASE
455-7052-01	ARTEX INSTALL KIT CANADAIR
455-7101	ARTEX ELT RB406-1HM BASE PAC (ITAR)
455-7421	ARTEX INSTALL KIT B/C-406 ELT
455-7422	ARTEX INSTALL KIT C-406-N ELT
455-7423	ARTEX INSTL KIT ME406/ELT1000
455-9700	ARTEX SWITCH RMT W/INSTL KT BK
455-9701	ARTEX SWITCH RMT W/INSTL KT GY
455-9703	ARTEX SWITCH RMT NVP BLK ITAR
500-0079	PRELIM, FIXTURE, ME406 G-SWITC
500-3000	ARTEX ATTENUATOR, 30DB

Part Number	Description
500-3200	ARTEX ATTENUATOR, 20DB
591-0003	LABEL 452-0023 REMOTE (must by 10)
591-0427	LABEL, "CAUTION" ELT
591-0428	LABEL, ELT CAUTIONARY USE ADVISORY
611-0110	CABLE C406/110 SERIES PROGRAM
611-0111	CABLE C406-N/PA SERIES PROGRAM
611-0112	CABLE ME406, ELT345/1000 PROGM
611-1041	CABLE COAX RG-178 SMC TO LEED
611-1046	CABLE COAX RG-178 (SMC TO TPS)
611-4010	ARTEX HARNESS DGL-1
611-6010	CABLE COAX BNC TO BNC 10FT
611-6013	CABLE COAX ELT 110-4 (DISCONTINUED)
611-6013-04	CABLE COAX BNC TO BNC 6 FT
611-6013-06	CABLE COAX BNC TO BNC 7' (DISCONTINUED)
611-6013-11	CABLE BNC TO BNC 142 (15FT)
611-6052	CABLE COAX TNC TO TPS 6FT
611-6411	COAX CABLE 8' BNC-BNC RG-142
611-6412	CABLE COAX 8' TNC-TPS RG-142
850-0920	SILICON DILECTRIC COMPOUND
850-9003	LUBRIPLATE