



Exhibit C - LIST OF OEM PRODUCTS SURPORTED BY KARWC

1/3

OEM products to be serviced by Kannad Approved Repair & Warranty Center		
Part Number	Designation	Associated CMM/ACMM
S1819502-02	ELT, KANNAD 406 ATP	CMM 25-63-02
S1819524-01	MOUNTING BRACKET, 2 STRAPS	ACMM 25-63-10
S1820502-01	ELT, KANNAD 406 AP	CMM 25-63-01
S1820502-02	ELT, KANNAD 406 AP	CMM 25-63-01
S1820502-04	ELT, KANNAD 406 AP-H	CMM 25-63-01
S1820511-01	MOUNTING BRACKET, 1 STRAP	ACMM 25-63-11
S1820511-02	MOUNTING BRACKET, AS	ACMM 25-63-12
S1820511-03	CARRY-OFF BAG LONG	ACMM 25-63-13
S1820511-04	CARRY-OFF BAG SHORT	ACMM 25-63-13
S1820511-05	MOUNTING BRACKET, AS-PLUS	ACMM 25-63-12
S1820513-02	REMOTE CONTROL PANEL, RC500-320	ACMM 25-63-24
S1820513-03	REMOTE CONTROL KIT, RC100	ACMM 25-63-20
S1820513-05	REMOTE CONTROL PANEL, RC400	ACMM 25-63-23
S1820513-07	REMOTE CONTROL KIT, RC150	ACMM 25-63-20
S1820513-09	REMOTE CONTROL PANEL, RC300	ACMM 25-63-22
S1820513-10	REMOTE CONTROL PANEL, RC300-NVG	ACMM 25-63-22
S1820513-11	REMOTE CONTROL PANEL, RC200	ACMM 25-63-21
S1820513-14	REMOTE CONTROL PANEL, RC200-NVG KITS	ACMM 25-63-21
S1820513-15	REMOTE CONTROL PANEL, RC800	ACMM 25-63-28
S1820513-18	REMOTE CONTROL PANEL, RC200	ACMM 25-63-21
S1820513-19	REMOTE CONTROL PANEL, RC200-NVG	ACMM 25-63-21
S1820513-20	REMOTE CONTROL PANEL, RC200 COMPACT	ACMM 25-63-21
S1820513-21	REMOTE CONTROL KIT, RC102	ACMM 25-63-31
S1820513-26	REMOTE CONTROL PANEL, RC310	ACMM 25-63-33
S1820514-01	PROGRAMMING DONGLE	ACMM 25-63-40
S1820514-04	PROGRAMMING DONGLE A320	ACMM 25-63-41
S1820514-05	PROGRAMMING DONGLE A330 A340	ACMM 25-63-42
S1820514-06	PROGRAMMING DONGLE ASSY	ACMM 25-63-44
S1820514-07	PROGRAMMING DONGLE INTEGRA L/R	ACMM 25-63-45



Exhibit C - LIST OF OEM PRODUCTS SURPOTED BY KARWC

2/3

OEM products to be serviced by Kannad Approved Repair & Warranty Center		
Part Number	Designation	Associated CMM/ACMM
S1820514-08	DONGLE IF GPS RS232	ACMM 25-63-51
S1820514-11	PROGRAMMING DONGLE INTEGRA-SA	ACMM 25-63-47
S1820514-14	WATER SWITCH SENSOR KIT	ACMM 25-63-43
S1820515-06	BUZZER ASSEMBLY	ACMM 25-63-25
S1821502-01	ELT, KANNAD 406 AF	CMM 25-63-01
S1821502-02	ELT, KANNAD 406 AF	CMM 25-63-01
S1821502-06	ELT, KANNAD 406 AF (6D)	CMM 25-63-01
S1822502-01	ELT, KANNAD 406 AF-H	CMM 25-63-01
S1822502-02	ELT, KANNAD 406 AF-H	CMM 25-63-01
S1823502-01	ELT, KANNAD 406 AS	CMM 25-63-01
S1823502-02	ELT, KANNAD 406 AS	CMM 25-63-01
S1823502-03	ELT, KANNAD 406 AS-TNC	CMM 25-63-01
S1823502-05	ELT, KANNAD 406 SURVIVAL	CMM 25-63-01
S1824502-01	ELT, KANNAD 121 AF	CMM 25-63-01
S1824502-02	ELT, KANNAD 121 AF	CMM 25-63-01
S1825501-01	ASSEY ELT-NAV INTERFACE CS144-RS	ACMM 25-63-50
S1825501-02	ASSEY ELT-NAV INTERFACE CS144-A	ACMM 25-63-50
S1826502-02	ELT, KANNAD 121 AF-H	CMM 25-63-01
S1840501-01	ELT, KANNAD 406 AF-COMPACT	CMM 25-63-03
S1840501-04	ELT, KANNAD 406 AF-COMPACT (ER)	CMM 25-63-03
S1840502-01	MOUNTING BRACKET, KANNAD 406 AF-COMPACT	ACMM 25-63-29
S1840502-02	KIT, COMPACT UNIVERSAL MOUNTING BRACKET	ACMM 25-63-30
S1850501-01	ELT, AP INTEGRA (ER)	CMM 25-63-06
S1850501-02	ELT, AP INTEGRA	CMM 25-63-06
S1850501-03	ELT, AP INTEGRA (ER-N)	CMM 25-63-06
S1850551-01	BRACKET UNIVERSAL for INTEGRA ARINC e-NAV for ELT (AP)	ACMM 25-63-34
S1850551-02	BRACKET UNIVERSAL for INTEGRA ARINC e-NAV for ELT (AF)	ACMM 25-63-34
S1850551-03	MOUNTING BRACKET INTEGRA AP	ACMM 25-63-34
S1850551-04	MOUNTING BRACKET INTEGRA AF	ACMM 25-63-34

